



red spot



Professional stain spotter for treating blood, milk, food & body fluid stains

PRODUCT CODE	212
APPEARANCE	clear near colourless liquid
REACTION	alkaline
STORAGE	above 5°C
STANDARD PACK SIZE	5ltr
ALSO AVAILABLE IN	10ml roll-on applicator, 250ml, 20L

- Developed in consultation with professional cleaners for tackling specific problem stains.
- Treat blood, milk, cream, egg, mayonnaise and chocolate stains.
- Remove urine, vomit and body fluids.
- Ready to use straight from the bottle.
- Available as 10ml mini roll-on or 250ml applicator bottles. Refills available in 5ltr drums.

Ideal spotter chart

	red spot (Rs)	orange spot (Os)	yellow spot (Ys)	green spot (Gs)	blue spot (Bs)	rust remover (Rr)
adhesive						
bird						
blood	●					
chocolate	●					
coffee		●				
cosmetics				●		
crayon					●	
cream						
egg	●					
fruit & juices		●				
grass						
gravy			●			
grease				●		
ice cream	●					
ice lollies	●					
ink						
jelly		●				
lacquer						
liqueur		●				
lipstick					●	
milk						
milk-egg						
mayonnaise	●					
milk	●					
mineral water					●	
mud		●				
mustard						
nail polish						
nail varnish						
oil						
ointment						
paint						
perfume						
perspiration						
resin						
rubber cement						
sand dressing						
sauce		●				
shoe polish						
tar						
tea						
tomato juice						
urine	●					
vase						
wine						
vomit	●					

Apply prior to wet washing or dry cleaning for effective removal of rust stains.

ashore spotbuster
Use on any surface for water based stains including grease, perfume, detergent and fabric softener. For dry cleaning, refer to literature.

ashore
These are tried & tested on all of the above stain categories, detergent and fabric softener. Made in the UK.

100ml roll-on applicator

250ml applicator

5ltr drum

* All systems are suitable for use in dry cleaning and wet cleaning but always ensure that green spot is flushed prior to wet cleaning.

www.idealmanufacturing.com

How to use

Refer to Ideal Spotter Chart.

Apply spotter directly to stain. Allow time to penetrate. Gently work stain with a spotting bone, brush or Ideal roll-on applicator. Flush area with water or steam. Avoid dry steam on blood stains. For set blood stains saturate with red spot and allow extended time for solubilisation. Clean treated garments as normal.

Dyestuffs can often display poor fastness to spotting, so we recommend that seam tests are always carried out before application.

It's always better to clean as soon as possible after application.

You should only pre spot garments in time for the next load.

For further process information speak to an Ideal technical representative.

Health & safety

Available on request. Store above 5°C.

Ideal Manufacturing Ltd
Atlas House, Burton Road, Finedon,
Northants, NN9 5HX

01933 681 616
hello@idealmanufacturing.com

Follow us @IdealManLtd

www.idealmanufacturing.com

