

Ideal

spotter chart



red spot
(Rs)



orange spot
(Os)



yellow spot
(Ys)



green spot
(Gs)



blue spot
(Bs)

adhesive			✓	
biro			✓	✓
blood	✓			
chocolate	✓	✓		
coffee		✓		
cosmetics			✓	✓
crayon			✓	
cream	✓			✓
egg	✓			
fruit & juices		✓		
grass		✓		
gravy		✓	✓	
grease			✓	
ice cream	✓			
ice lollies	✓			
ink			✓	
jelly		✓		
lacquer			✓	
liqueur		✓	✓	
lipstick			✓	✓
make-up			✓	✓
mayonnaise	✓			
milk	✓			
mineral water				✓
mud		✓	✓	
mustard		✓		
nail polish				✓
nail varnish			✓	
oil			✓	
ointment			✓	✓
paint			✓	
perfume				✓
perspiration		✓		
resin			✓	
rubber cement			✓	
salad dressing		✓	✓	
sauce		✓	✓	
shoe polish			✓	
tar			✓	
tea		✓		
tomato juice		✓		
urine	✓			
wax			✓	
wine		✓		
vomit	✓			

* All spotters are suitable for use in dry cleaning and wet cleaning but always ensure that green spot is flushed prior to wet cleaning.



rust remover
(Rr)

Apply prior to wet washing or dry cleaning for effective removal of rust stains.



**ashore
spotbuster**

A spray on prespotter for water based stains. Always leave to dry completely prior to cleaning.



ashore

Have you tried the rest of the ashore range: prespotters, detergents and finishing agents. Made in the UK.



REFILLS

All spotters refillable
in 5L drums.



